
MINI COOLING FAN





Open the watertank cover, pourin tap water ormineral water, and then cover the water tank cover.



When filling with water:
One gear can be sprayed for 12 hours continuously.
The second gearcan be sprayed for 4hours continuously.

continuously.
The thira ginarcanbe sprayed for 2.5hours continuously.




Open the perfume cover, drop perfume onthe cotton block,and then cover the perfume cover.






Press the switch cover



Press the button to select the function



(3) (\$) (\$) (Ø) Fan Spray 7color Timed shutdown








 Open the water tank cover and wipe the water tank with a wetcloth, The clean design of the water tank can effectively preventthe breeding of bacteria and protect your health



Squeeze eitherend of the upper and lower ends of the air outletwindow towards the middle to remove the air outlet window, andthen wipe the fan blades with a wet rag to wash the air outletwindow separately.



When carrying or not using, please pour out the water in thewater tank to prevent overflow or bacteria in the water tankfor a long time.



When the sensor detects that the watercontent in the watertank is too low,it will stop the spray automaticalty, add wateragain and press the spray switch to spray. Only tap water or mineral water can be added



O not open the spray at the same time when the wind is blowingdown.Otherwise,the fan wilt absorb the water mist and formwater droplets.



When the atomizer is covered with water droplets, it will delaythe spray and wait for a few seconds to spray properly.




The output current of power supply The output current of power supply equipment shall be greater thanor equal to 2a, otherwise the product will not work normally due toinsuf ficient power supply. The USB interface current output of some laptops, computer hosts, mobile power supplies, plug-ins and charging plugs is lessess than 2A ltwillcause insufficient power supply and shutdown.

6 Insertthe powercord into the power supply interface andturn on the power.







When the product is working and there is waterin the water tank please do not titt the product and be sure to keep it horizontat because of the density of water, pure water or distilled water canaffect the spray effect and stop spraying. Only lap water or mineralwater can be added.

- Warning

 When you carry it with youordon't use it, please pour out the water in the water tank, wipe the water tank dry with a cloth, and cover thewater tank cover to prevent the water from staying in the water tankfor a long time to breed bacteria.

 If you accidentally push down theproduct or add water to overflow, please cut off the power supply immediately to avoid leakage.

 Thepowersupply interface of the product must be completely directore reuse.

 Please clean the water tank and fan regularly. Clean the water tankwith a damp cloth. The product is not completely waterproof, it is forbidden to washor soak the whole productunder water to avoid water short circuitand dampe.

 Product parameter description

Produce name	AIRCOOLER FAN
Power	Max.10W
Voltage	5V
Electric current	2A
Blowing distance	Maximum 25m
Interface	USBtype-Cinterface
Atomization quantity	Maximum 225m/h
Spray time	2.5-12 hours

- Only [tap water] or [mineral water]canbe ddedto the water tank.

 Because ofthe density of water, pure water can cause the spray to stop
- Recuise of the density of water, pure water can cause the spray to stop
 Please ensure that the outputcurrent of
 power supply equipment isgreater the or
 equal to 2A.
 The USB residence current object of some layeop, compreher bots,
 the USB residence current object of some layeop, compreher bots,
 which willess control object and other playing is the time 2a,
 which willess to insufficient power supply and shutdown
 When the spray non 22Le is, covered with
 water droplets, it will delay the spray and
 wait for a few seconds to spray
 properly.



